

Ω OMEGA™

HX80A SERIES OPERATORS MANUAL



Rev F February 2021

MADE IN

USA

Ω
® 1 YEAR
WARRANTY

ISO 9001
CERTIFIED
CORPORATE QUALITY

STAMFORD, CT

ISO 9002
CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK



OMEGAnet® Online Service
omega.com

Internet e-mail
info@omega.com

Servicing North America:

U.S.A.:
ISO 9001 Certified

One Omega Drive, P.O. Box 4047
Stamford, CT 06907-0047
TEL: (203) 359-1660
FAX: (203) 359-7700
e-mail: info@omega.com

Canada:

976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928
FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342/1-800-TC-OMEGA®
Customer Service: 1-800-622-2378/1-800-622-BEST®
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico:

En Español: (001) 203-359-7803
e-mail: espanol@omega.com
FAX: (001) 203-359-7807

Servicing Europe:

Czech Republic:

Frystatska 184, 733 01 Karvina, Czech Republic
TEL: +420 (0)59 6311899
FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342
e-mail info@omega.cz

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0
FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom:

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611
FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.

HX80A SERIES

QUICK STARTUP GUIDE – Page 1

STARTUP

WHEN USING PROBE ONLY:

1. Mount the Probe in position to measure the desired gas.
2. Connect Probe wiring by cutting off connector or using a mating connector (HX85A-COB), as shown below:

ITEM	RIBBON CABLE WIRE #
Power Supply – Pos.	7
Power Supply – Neg.	1 (blue tracer)
Output 1 – Pos.	2
Output 2 – Pos.	6
Output 3 – Pos.	8
Output Common	4
Serial Output – TX	5
Serial Output – RX	3



HX85A-COB (for HX85A probe series only)

Notes: Connect only the Outputs desired. See drawing in the HX80A Manual for further connection details.

Do not apply DC Power until all wiring is completed.

HX80A SERIES

QUICK STARTUP GUIDE – Page 2

WHEN USING PROBE WITH ELECTRONICS UNIT:

1. Mount the Probe and Electronics Unit.
2. Connect cable from Probe to Electronics Unit (if applicable).
3. Connect Power Supply to Electronics Unit.
4. Connect Analog Outputs of Electronics Unit.
5. Connect Digital Output of Electronics Unit.
6. Connect Alarm Relays of Electronics Unit.
7. Connect RS-232 Serial Port of Electronics Unit.

ITEM	CONN.	TERM.
Power Supply (+)	J8	2
Power Supply (-)	J8	1
Analog Out 1 (+)	J9	1
Analog Out 1 (-)	J9	2
Analog Out 2 (+)	J9	3
Analog Out 2 (-)	J9	4
Analog Out 3 (+)	J9	5
Analog Out 3 (-)	J9	6
Alarm Relay 1	J2	1
Alarm Relay 1	J2	2
Alarm Relay 2	J2	3
Alarm Relay 2	J2	4
RS-232 TX	J6	2
RS-232 RX	J6	3
RS-232 RTN	J6	5

Notes:

Connect only the Outputs desired.

TABLE OF CONTENTS	Page
1.0 Quick Startup	1
List of Illustrations	4
List of Tables	4
2.0 Introduction	6
2.1 General Description	6
2.2 Specifications Summary	7
2.3 Model Descriptions	8
2.4 Available Options	9
3.1 Installation	11
3.2 Mounting the Probe	11
3.2 Mounting the Electronics Unit	12
3.3 Electrical Wiring	12
3.3.1 Probe Only	12
3.3.2 Probe with Electronics	15
4.0 Basic Block Diagram	18
4.1 Probe Assembly	18
4.2 Electronics Module	18
4.3 Complete System	20
5.0 Operation	21
5.1 Initial Bench Testing	21
5.2 Normal Operation	21
5.3 Factory Default Conditions	21
5.4 RS-232 Serial Port	23
5.4.1 Serial Port Setup	23
5.4.2 Changing the Digital Display	23
5.4.3 Changing the Output Ranges	24
5.4.4 Programming the Alarm Relays	25
5.4.5 Calibrating the Analog Outputs	26
6.1 Maintenance	27
6.2 Sensor Circuit Board	27
6.1.1 Replacing the Sensor Board	27
6.1.3 Sensor Reassembly	27
7.0 Specifications	28

LIST OF ILLUSTRATIONS	Page
2-1 HX80 Configurations	6
3-1 System with Sample Cell	11
3-2 Installing the Mounting Lugs	12
3-3 Probe Wiring, Ribbon Cable	14
3-3a Probe Wiring	15
3-4 Electronics Unit Wiring	17
4-1 Probe Block Diagram	18
4-2 System Block Diagram	20
6-2 Sensor Exploded View	27

LIST OF TABLES	Page
2-1 Standard Configurations	8
2-2 Measurement Ranges	10
3-1 Probe Wiring, Ribbon Cable	13
3-11a Probe Wiring	14
3-2 Electronics Wiring	16
3-3 Serial Port Wiring	16
5-1 Standard Output Scaling	22

2.1 INTRODUCTION

2.2 GENERAL DESCRIPTION

The HX80A Series is a family of humidity probes and electronic modules that offer a variety of measurement parameters with high accuracy. In addition to Percent Relative Humidity (%RH), probes are available to also measure Temperature and Pressure. Electrical analog and digital outputs are provided for not only these measured parameters but may be provided for microprocessor- computed parameters as well. These include parts-per-million by volume (ppmv), parts-per-million by weight (ppmw), grains of water per pound of dry gas (gr/lb), and others.

The HX80A system is designed for ease of installation and operation. Field-replaceable sensor modules have standardized outputs for interchangeability without recalibration. The power requirement is a common unregulated DC power supply. User-available electrical outputs include linear analog voltage (or optional current), a digital bi-directional serial port, and alarm relays. Mounting options include Wall Mount, Remote Mount, and Duct Mount configurations. Additional options include high temperature and high-pressure probes. A remote or local Display Unit (Type DIS) is available, with a two-line LCD display, alarm relays, and three 4 to 20 mA electrical outputs.

Figure 2-1 Some of the Available HX80A Configurations



a. Stand-alone Probe



b. Remote Mount with Display Option



c. Wall Mount Unit

2.2.1 STAND-ALONE PROBE

Analog Outputs:	0 – 10 Vdc (X3)
Digital Output:	RS-232C
Power Supply:	18 to 30 Vdc, unregulated, 50 mA max.
RH Accuracy:	+/- 1% nominal
Temp. Accuracy:	+/- 0.5°C
Mounting:	Cable Length: 6 feet
Fitting:	¾ inch stainless steel NPT thermocouple fitting
Dimensions:	Length: 8 inches Diameter: ¾ inch
Materials:	Housing: Stainless Steel Filter: Sintered Stainless Steel (removable)

2.2.2 PROBE WITH ELECTRONICS UNIT (remote, wall, duct)

Analog Outputs:	4 to 20 mA (X3)
Digital Output:	RS-232C, bi-directional
Alarm Relays:	Form A (SPST, NO) X2
Power Supply:	18 to 30 Vdc unregulated, 50 mA max.

RH Accuracy: +/- 1% nominal

Temp. Accuracy: +/- 0.5°C

Display: 2 line LCD

Electronics Housing Protection:
IP66 (NEMA 4X) Dust tight and moisture resistant

Table 2-1 HX80A, Standard Available Configurations

	Probe (only)	Probe with electronics unit
HX85A	x	
HX85BA	x	
HX85PA	x	
HX86A		X
HX86BA		X
HX86PA		X
HX86A-W		X
HX86BA-W		X
HX86A-D		X
HX86BA-D		X

2.3 HX80A SERIES MODEL DESCRIPTIONS

HX85A – A Humidity/Temperature probe providing RH, Dew Point, and Temperature outputs with an operating temperature up to 120C.

HX85BA – A Humidity/Temperature/Barometric Pressure probe providing RH, Temperature, and Pressure outputs with an operating temperature up to 120C.

HX85PA – A Humidity/Temperature/High Pressure probe providing RH, Temperature, and Pressure outputs with an operating temperature up to 120C.

HX86A – A Humidity/ High Temperature probe providing RH, Temperature, and Dew Point outputs, with remote Electronics Unit including Digital Display with an operating temperature up to 120C.

HX86BA – A Humidity/High Temperature/Barometric Pressure probe providing RH, Temperature, and Pressure outputs, with remote Electronics Unit including Digital Display with an operating temperature up to 120C.

HX86PA – A Humidity/High Temperature/High Pressure probe providing RH, Temperature, and Pressure outputs, with remote Electronics Unit including Digital Display with an operating temperature up to 120C.

HX86A-W – A wall mount Humidity/ High Temperature probe providing RH, Temperature, and DewPoint outputs, with Electronics. Unit includes Digital Display with an operating temperature up to 60C.

HX86BA-W – A wall mount Humidity/High Temperature/Barometric Pressure probe providing RH, Temperature, and Pressure outputs, with Electronics Unit including Digital Display with an operating temperature up to 60C.

HX86A-D – A duct mount Humidity/ High Temperature probe providing RH, Temperature, and DewPoint outputs, with remote Electronics Unit including Digital Display with an operating temperature up to 120C.

HX86BA-D – A duct mount Humidity/High Temperature/Barometric Pressure probe providing RH, Temperature, and Pressure outputs, with remote Electronics Unit including Digital Display with an operating temperature up to 120C.

Wall Mount Configuration

2.4 AVAILABLE OPTIONS

HX86A-DIS – Remote electronics module with two-line LCD digital display, three 4 to 20 mA analog outputs, RS-232C, and two programmable alarm relays. This unit can be added to existing Probes (HX85A series in the field).

HX80- SENSOR – Field-replaceable sensor module for RH/Temperature. Interchangeability accurate to published specification.

HXP80-SENSOR – Field-replaceable sensor module for RH/Temperature/Pressure. Interchangeability accurate to published specification.

HXB80-SENSOR – Field-replaceable sensor module for RH/Temperature/Barometric Pressure. Interchangeability accurate to published specification.

HX80-CHAMBER – Sample chamber with inlet and outlet fittings.

HX85A-COB – An adapter board for HX85 series only. It is used as a connecting board for easy wiring.

Table 2-2 HX80A Series Sensor Actual Measurement Ranges.

MODEL NO.	OUTPUT 1	OUTPUT 2	OUTPUT 3
HX85A	PERCENT RH	AIR TEMP.	DEW POINT
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	-60 to +40°C
HX85BA	PERCENT RH	AIR TEMP.	BAR. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	10 to 1100 MB
HX85PA	PERCENT RH	AIR TEMP.	ABS. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	0 to 200 psia
HX86A	PERCENT RH	AIR TEMP.	DEW POINT
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	-60 to +40°C
HX86BA	PERCENT RH	AIR TEMP.	BAR. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	10 to 1100 MB
HX86PA	PERCENT RH	AIR TEMP.	ABS. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	0 to 200 psia
HX86A-W	PERCENT RH	AIR TEMP	DEWPOINT
MEASUREMENT RANGE	5 TO 95%	-20 to +60°C	-60 to +40°C
HX86BA-W	PERCENT RH	AIR TEMP	BAR. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +60°C	10 to 1100 MB
HX86A-D	PERCENT RH	AIR TEMP	DEWPOINT
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	-60 to +40°C
HX86BA-D	PERCENT RH	AIR TEMP	BAR. PRESSURE
MEASUREMENT RANGE	5 TO 95%	-20 to +120°C	10 to 1100 MB

- NOTES:**
- 1. THE STANDARD RANGES ARE FIELD PROGRAMMABLE VIA THE RS-232 PORT.**
 - 2. SEE TABLE 5-1 FOR STANDARD FACTORY SCALING.**

3.1 INSTALLATION

3.2 MOUNTING THE PROBE

The remote probe includes a $\frac{3}{4}$ NPT stainless steel mounting sleeve, commonly called a thermocouplemount. It has a tapered male $\frac{3}{4}$ -inch NPT pipe thread. The female mating fitting, user- supplied, should be mounted in a gas-tight manner to a flat surface of a duct, pipe or chamber wall containing the gas to be measured.

To install the mount and Probe:

1. Separate the two parts of the mounting sleeve.
2. Screw the front portion of the mounting sleeve (the tapered NPT fitting) into the pre-mounted mating fitting. Teflon™ tape may be used for a good seal. Do not over-tighten.
3. Insert the Probe into the rear portion and screw this part of the mount into the previously mounted front portion, so that the Probe is gripped snugly. Do not over-tighten. As much of the Probe as possible should protrude inside the area to be measured, to avoid possible laminar flow errors.

If the optional sample chamber is to be used, simply screw it down to any flat surface, and connect $\frac{1}{4}$ inch OD tubing to the inlet and outlet compression fittings.



Figure 3-1, System with Sample Cell, ready for mounting


3.3 MOUNTING THE REMOTE ELECTRONICS MODULE

MOUNTING CONSIDERATIONS

1. If the Digital Display has been provided, is it easily visible?
2. Is the location convenient for routing electrical wiring?
3. Is the module within 6 feet (1.8 meters) of the Sensor location?

Use a small hammer to tap in the pins that hold the four corner mounting lugs in place. See Figure 3-2 below. Mount the box to a flat surface with screws or bolts through the 4 mounting holes.

Figure 3-2 a,b,c,d
Installing Mounting Lugs



3.4 ELECTRICAL WIRING

3.3.1 PROBE ONLY

See Wiring Table 3-1 and Figure 3-3 below.

1. Connect Power Supply wiring as shown.
2. Connect the Analog Output wiring as shown. Three 0 to 10Vdc outputs are available. Connect Outputs 1, 2, and 3 as required.
3. Connect the RS-232 Serial Output if desired. Only 2 wires are required if the output is needed for transmitting information only. A third wire is added for bi-directional communications with the serial port.

**4. Table 3-1 HX80A Series Probe (with Ribbon Cable)
Wiring Table**

ITEM	RIBBON CABLE WIRE #
Power Supply – Pos.	7
Power Supply – Neg.	1 (blue tracer)
Output 1 – Pos.	2
Output 2 – Pos.	6
Output 3 – Pos.	8
Output Common	4
Serial Output – TX	5
Serial Output – RX	3

HX85A-COB- connector board

HX85A series connected to the HX85A-COB



HX85A-COB



With the HX85A plugged into the HX85A-COB pinout

ITEM	HX85A-COB #
Power Supply – Pos.	7
Power Supply – Neg.	1
Output 1 – Pos.	2
Output 2 – Pos.	6
Output 3 – Pos.	8
Output Common	4
Serial Output – TX	5
Serial Output – RX	3




Figure 3-3 HX80A Series Probe (with Ribbon Cable)
Wiring Diagram

Table 3-1a HX80A Series Probe (with Discrete Wires)
Wiring Table

ITEM	COLOR CODE
Power Supply – Pos.	Yellow
Power Supply – Neg.	Green
Output 1 – Pos.	Brown
Output 2 – Pos.	Red
Output 3 – Pos.	Orange
Output Common	Black
Serial Output – TX	Blue
Serial Output – RX	White
Serial Common	Green




Figure 3-3a HX80A Series Probe (with Discrete Wires) Wiring Diagram

3.3.2 PROBE WITH ELECTRONICS MODULE

See Tables 3-2, 3-3, and Figure 3-4 below.

Notes:

1. **Cable bushings are shipped separately. Carefully tap out the desired knockouts, and mount the bushings.**
2. **We recommend that you route the Probe Cable through a bushing on the left. Route all other wiring through the bushing on the right.**

1. Run the cable from the Probe to the connector labeled Probe Input.
2. Wire the Power Supply as shown in Table 3-2.
3. Wire the three 4 to 20 mA Analog Outputs and Alarm Relays as shown in Table 3-2 if desired.
4. Connect to the RS-232C Serial Port at J6 if desired.


Table 3-2 Electronics Unit Wiring Table

ITEM	CONN.	TERM.
Power Supply (+)	J8	2
Power Supply (-)	J8	1
Analog Out 1 (+)	J9	1
Analog Out 1 (-)	J9	2
Analog Out 2 (+)	J9	3
Analog Out 2 (-)	J9	4
Analog Out 3 (+)	J9	5
Analog Out 3 (-)	J9	6
Alarm Relay 1	J2	1
Alarm Relay 1	J2	2
Alarm Relay 2	J2	3
Alarm Relay 2	J2	4

Table 3-3 J6 Wiring Table

DB-9 SERIAL CONNECTOR	ITEM
Pin 2	TX
Pin 3	RX
Pin 5	RTN

Figure 3-4 Electronics Unit Wiring



4.1 BASIC BLOCK DIAGRAM THEORY OF OPERATION

4.2 PROBE ASSEMBLY

See Figure 4-1, the Probe Assy. Basic Block Diagram.

The Probe Assembly is a stand-alone, completely self-contained measuring system. All units include the RH and Temperature Sensors, and some optional probes include a Pressure Sensor as well. The field-replaceable Sensor Circuit Board has standardized output levels for all three measured parameters. Therefore, boards may be quickly replaced while in operation without the need for recalibration, maintaining full system accuracy. The Microprocessor performs the system control, parameter calculation, and serial digital communications. Digital-to-Analog (D-A) conversion provides three 0 to 10 Vdc linear Analog Outputs corresponding to the measured and/or calculated parameters.

The serial digital RS-232 interface is bi-directional, allowing the user to not only receive and record measured information, but to remotely control output scaling, alarm relay setpoints, and other functions as well.




Figure 4-1 Basic Block Diagram, Probe Assy

4.3 HX86A-DIS ELECTRONICS MODULE


Although the Probe may be used as a stand-alone measuring device (HX85A), it also may be connected to the type DIS remote display unit, for additional capability. This combination is called the HX86A. A complete HX86A system consists of the Probe, the interconnecting 6 foot (1.8 meter) cable, and the electronics module. Outputs of the unit include a Serial Port, two Alarm Relays and three 4 to 20 mA Analog Outputs. A two-line LCD Digital Display is also included.

4.4 THE COMPLETE HX86A SYSTEM

Figure 4-2 is a basic block diagram of the complete Humidity, Temperature and Pressure measuring system. The remote Probe is connected, via the attached cable, to the electronics module. The system is completely controlled by the microprocessor in this module.

The three sets of analog voltage outputs from the Probe are routed through the Analog Scaling and Selection stage. The scaling of these output signals may be programmed by the user to any desired range by using the RS-232 Serial Port. The bi-directional RS-232 is brought out to a connector in the electronics module. The user can also program the two Alarm Relay set points via this digital interface. The built-in LCD Digital Display, which provides information on all measured parameters, is also controlled by the microprocessor. In addition, the microprocessor is used to calculate other parameters than those directly measured by the sensors in the Probe. These may be shown on the Digital Display, and they are also available on both the analog and digital (RS-232) outputs. The Alarm Relays may also be set for these calculated values.

Figure 4-2 System Basic Block Diagram



5.1 OPERATION

5.2 INITIAL BENCH TESTING

New units may be tested on the bench before installation, if desired.

For units consisting of the Probe only –

1. Connect a proper Power Supply to the correct wires.
Caution: Observe polarity!
2. Using a DC Voltmeter, measure the 0 to 10 Vdc Output and confirm that it corresponds to the room condition. (Humidity, Temperature, etc.)

For systems consisting of the Probe and the Electronics Unit –

1. Connect the Probe to the Electronics Module.
2. Connect a proper Power Supply to the correct terminals.
Caution: Observe polarity!
3. Measure the 4 to 20 mA Output as above, or read the Digital Display.
Confirm that the reading corresponds to the room condition. (Humidity, Temperature, etc.)

5.3 NORMAL OPERATION

Note:

This section assumes that all required electrical wiring and mounting has been completed. See the Installation section for further information if necessary.

Use of the HX80A series of probes is extremely simple. There are no controls to operate during normal use, as these devices are designed for long-term unattended operation. With the Analog Outputs, Digital Outputs, and/or Alarm Relays connected to a Data Acquisition System, Recorder, Process Controller, Computer, or Terminal, the user has only to periodically monitor the system for normal operation.

5.4 FACTORY DEFAULT RANGES

The scaling of the default measurement ranges may be changed in the field via the Serial Port if required. See Section 5.4 below for range-changing instructions.

The following ranges are set at the Factory. They correspond to the three separate 0 to 10 Vdc analog outputs that are provided. The scaling of these ranges may be changed in the field via the Serial Port if required.

Table 5-1 Standard Output Scaling

MODEL	R.H.	TEMP.	PRESSURE	DEW POINT
HX85A	0 to 100%	-20 to 80°C/120 °C	N/A	-60 to 40°C
HX85BA	0 to 100%	-20 to 80°C/120 °C	750 to 1100 mb	
HX85PA	0 to 100%	-20 to 80°C/120 °C	0 to 200 psia	
HX86A	0 to 100%	-20 to 120°C	N/A	-60 to -40°C
HX86BA	0 to 100%	-20 to 120°C	750 to 1100 mb	
HX86PA	0 to 100%	-20 to 120°C	0 to 200 psia	

Notes:


- 1. Although the Factory default range for the HX85BA, and the HX86BA is 750 to 1100 mb, it can be reprogrammed in the field over a range of 10 to 1100 mb.**
- 2. If you have the Type DIS Humidity Multi-I/O accessory, the Analog Outputs are 4 to 20 mA.**

5.5 USING THE RS-232C SERIAL PORT TO PROGRAM YOUR SETTINGS

5.4.1 SERIAL PORT SETUP

Plug a standard RS-232 cable into the DB-9 connector on the circuit board in the Type DIS Humidity Multi I/O Electronics Unit. Plug the other end into your terminal or computer. Use a Terminal Emulation program such as Hyperterminal. Program the Hyperterminal settings as follows:


- Baud Rate: 19.2K
- Data Bits: 8
- Parity: None
- Stop Bit: 1
- Flow Control: None



You should now see flowing data on your monitor, displaying the same information as the Multi I/O front panel Digital Display, with a rapid update rate. If you do not, check your serial port settings and connections.


NOTE: WHEN PROGRAMMING ALPHABETIC CHARACTERS, USE UPPER CASE ONLY.

5.4.2 CHANGING THE DIGITAL DISPLAY



You can select any measured or calculated parameters to appear on the front panel Digital Display. Proceed as follows:



Press the "Escape" key on your keyboard. You will see "D)isplay C)al Outputs" as



shown here.


Press "D", selecting to change the Display. (We will C)alibrate the Outputs later.) You will then be given a choice whether to keep the present settings or to change them. For this example, we will C)hange them. Press

“C”. You can then select the parameter to insert by cycling through the options using the Space Bar. In this case, we will change VALUE 1, the Dew Point reading, from DP°C to DP°F. Press Enter to save your change and advance to the next value. Next, do the same for Air Temperature. When completed, press Enter again to save and advance. For this example, we will choose not to change the %RH value. Instead, press “X” for eX)it).





When programming is completed, press “A” to accept the changes.

5.4.3 CHANGING THE OUTPUT RANGES





The next window to be seen will be the Output Settings screen. Here, you can modify the 4 to 20 mA Analog Output ranges. To enter this mode, press “C” for C)hange. You will see the Set Output screen shown here.




To change Output 1, select “1”. You will see this screen, which shows the present settings for Output 1.

Example: We would like to change DP°F to a range of -40 to 200 °F. Press Enter. Enter -40. Press Enter again. Enter 200. Press Enter again. To Save the Changes, press “Y” for Y)es. To accept the changes, press “A” for A)cept.




5.4.4 PROGRAMMING THE ALARM RELAYS



The system will then step to the Alarm Relay mode. The two relays are Form A, (single-pole, single-throw), normally open. You can independently program the “ON” point and the “OFF” point for each relay. To enter the menu, press “C” for C)hange.


We would like to change Alarm 2 to these parameters:

Open > a reading of 10 °C
Close < a reading of 10 °C




NOTE: IN ACTUAL OPERATION YOU SHOULD PROGRAM IN A SMALL OVERLAP, SO THAT THE RELAY DOES NOT CHATTER WHEN THE MEASURED READING IS EXACTLY AT THE SETPOINT. THIS IS CALLED “HYSTERESIS.”

Press “2” to set Alarm 2. You will note that Alarm 2 is set for Air Temperature, AT°C. Under OPEN, insert 10 and press “Enter.” Under CLOSED, insert 10 and press “Enter.”



You will be asked to Save the Changes. Press “Y” for Y)es.




Then, press “A” for A)cccept.

The program will then automatically return to the normal mode, displaying data that is continuously updated.


5.4.5 CALIBRATING THE ANALOG OUTPUTS

If you have a precise milliammeter, you can easily calibrate the three 4 to 20 mA analog outputs. In order to utilize this convenient capability, connect the meter in series with one of the analog outputs and the load.

Press the “Escape” key on your keyboard, which will interrupt the data stream and give you the choice of D)isplay or C)al Outputs. Select “C”.



In order to calibrate Output 1, press “1”. You will then be able to insert the desired current value at the 1/4 FS (25% of Full Scale) point and at the 3/4FS (75% of Full Scale) point. For 4 to 20 mA, 1/4FS is 8 mA, and 3/4FS is 16mA.



Insert these values, pressing “Enter” after each one. You will then see a range of what the milliammeter should read in order to attain the desired accuracy.

Then select “X” for eX)it. The system will now return to the normal data

reading mode.

6.1 MAINTENANCE

6.2 SENSOR CIRCUIT BOARD

Inside the barrel of the Sensor probe, mounted directly at the tip, is the plug-in sensor circuit board. This board has been calibrated at the Factory for a standard output level. Since all boards have been calibrated for the same normalized level, they may be replaced in the field without the requirement for recalibration, while maintaining the full published system accuracy specification.

6.1.1 REPLACING THE SENSOR CIRCUIT BOARD

The HX85A and HX86A series the filter cover is a screw on cover). It must be removed in order to gain access to the Sensor board.

Note: The small humidity sensor can be seen mounted near the tip of the board. This is fragile. Take care not to break it during board removal or installation.

6.1.3 SENSOR REASSEMBLY

Carefully plug the new sensor circuit board into the socket, noting that it is installed at the correct angle and properly aligned.

Figure 6-2 Sensor Exploded View
for the HX85A or HX86A series



7.0 SPECIFICATIONS

Note: See Table 2-2 for actual measurement ranges.

HX85A (Sensor Only)

Measured Parameters – RH/Temp.
RH Accuracy – +/- 1% RH
Temp. Accuracy – +/- 0.5°C
Output Information – RH, Temp., DP
Electrical Outputs – 0 to 10 Vdc (X3)
RS-232C

HX85BA (Sensor Only)

Measured Parameters – RH/Temp./Barometric Pressure
RH Accuracy – +/- 1% RH
Temp. Accuracy – +/- 0.5°C
Pressure Accuracy – +/- 5 mb
Output Information – RH, Temp., Pressure
Electrical Outputs – 0 to 10 Vdc (X3)
RS-232C

HX85PA(Sensor Only)

Measured Parameters – RH/Temp./Pressure
RH Accuracy – +/- 1% RH
Temp. Accuracy – +/- 0.5°C
Pressure Accuracy – +/- 0.75 psi
Output Information – RH, Temp., Pressure
Electrical Outputs – 0 to 10 Vdc (X3)
RS-232C

HX86A (Sensor with Electronics Module)

Measured Parameters – RH/Temp.
RH Accuracy – +/- 1% RH
Temp. Accuracy – +/- 0.5°C
Output Information – RH, Temp., DP
Electrical Outputs – 4 to 20 mA (X3)
RS-232C
Alarm Relays (X2)
Digital Display – LCD, 2-line

HX86BA (Sensor with Electronics Module)

Measured Parameters – RH/Temp./Barometric Pressure

RH Accuracy – +/- 1% RH

Temp. Accuracy – +/- 0.5°C

Pressure Accuracy – +/- 5 mb

Output Information – RH, Temp., Pressure

Electrical Outputs – 4 to 20 mA (X3)

RS-232C

Alarm Relays (X2)

Digital Display – LCD, 2-line

HX86PA (Sensor with Electronics Module)

Measured Parameters – RH/Temp./ Pressure

RH Accuracy – +/- 1% RH

Temp. Accuracy – +/- 0.5°C

Pressure Accuracy – +/- 0.75 psi

Output Information – RH, Temp., Pressure

Electrical Outputs – 4 to 20 mA (X3)

RS-232C

Alarm Relays (X2)

Digital Display – LCD, 2-line

Electrical Outputs

Systems with Probe only –

0 to 10 Vdc (X 3) @ 10 mA max.

RS-232C (bi-directional)

Systems with Probe and Electronics Unit—

4 to 20 mA (X3) into 500 Ω max.

Alarm Relay (X2) Form A (SPST, NO) rated at 3A/250 Vac

RS-232C (bi-directional)

Serial Output (All Units)

RS-232C to DTE device. 19.2 kilobaud, 8 bits data, 1 stop bit, no parity

Power Requirements

18 to 30 Vdc unregulated, 50 mA max.

Dimensions

Remote Sensor – Diameter: $\frac{3}{4}$ in. OD (1.9 cm)
Length: 8 inches (20.3 cm)

Cable Length – 6 feet (1.8 meters)

Consult Factory for longer lengths.

Electronics Module –

Outside Dimensions (HWD)

5.1 X 3.7 X 2.2 inches (13 X 9.4 X 5.6 cm)

Mounting Centers

4.52 X 3.11 inches (11.5 X 7.9 cm)

Sensor Pressure Rating

200 psia maximum

Sensor Sintered Filter

Material – Stainless Steel

Porosity – 40 microns

Notes